
START
Show banner
Set up phase map.
Set up interrupts.
Set up ports.
Set up statistic structures.
Sleep 1 second
Get statistics
Show statistics


ISR: Shaft moved
Read sensors
Empty read?
Yes
End
No
Set BLDC phase mark from sensors
Update statistic data
End